



http://links.vs-service.com/downloads/70-174_V02_DEEN_S800_Bodentraeger.pdf

Montageanleitung

Einbau der Einlegeböden

Bitte sorgfältig aufbewahren!

Transportsicherungen (1) entfernen. Bodenträger in die Rasterbohrungen schrauben (2) bzw. stecken (3). Die Stützen (4) direkt unter den Bodenträgern schräg einsetzen und bis zum Einrasten senkrecht drehen. Den Einlegeboden von oben auf 4 Bodenträgern mit Stützen auflegen.

Wichtig: Die Gewinde-Bodenträger (2) für den Einlegeboden in der Mitte des oberen Freiraums benutzen!

Assembly Instruction

Fitting the adjustable shelf inserts

Please store this document in a safe place!

Remove transportation locks (1). Screw (2) or insert (3) the shelf-insert carriers into the grid holes. Insert the supports (4) directly underneath the shelf-insert carriers at an angle and turn into the vertical position until they snap into place. Lay the adjustable shelf insert from above on 4 shelf-insert carriers with supports.

Important: Use the threaded shelf-insert carriers (2) for the adjustable shelf insert in the middle of the upper space.

