




Spare parts order form

Ergo-I, Ergo-II and Ergo-III

Ergo-I (height-adjustable students' tables)

The height of this table with its fixed horizontal top can be continuously adjusted using the winding lever.

W = 75 cm: 02970

W = 130 cm: 02971

Ergo-II (height-adjustable students' tables)

The height of this table with its inclining top can be continuously adjusted using the winding lever.

W = 75 cm: 02972

W = 130 cm: 02973

Ergo-III (height-adjustable students' tables)

The height of this table with its split inclining top can be continuously adjusted using the winding lever.

W = 75 cm: 02974

W = 130 cm: 02975

Note:

You can see which model your chair is by the sticker on the underside of the seat shell (with order number/ AB number, model number and delivery week/LW). Pupil chairs are colour-coded according to DIN EN 1729.

Please note the following markings:

blue = Model no longer available

ET0056 15.22

Plastic glide element with pin

Contents: 20 units to match 5 desks

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0057 30.44

Felt glide element with pin

Contents: 20 units to match 5 desks

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0068 43.21

Plug with kick protection

Contents: 20 units with fixing material for 5 desks

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0059 64.87

Castor with kick protection

Contents: 10 units with fixing material for 5 desks

for model: 02970, 02971, 02974, 02975



ET0060 31.72

Adjusting screw M10x25 with plastic glide element for mobile tables

Contents: 10 units with fixing material for 5 desks

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0626 34.25

Winding lever for height adjustment

Contents: 1 units, with fixing material

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0033 25.98

Storage basket set with angled back

for tables with fixed horizontal top

Contents: 2 units, with fixing material

for model: 02970, 02971



ET0065 20.25

Satchel hook

Contents: 4 units, with fixing material

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0066 72.05

Storage basket set

for tables with continuously inclinable top

Contents: 2 units, with fixing material

for model: 02972, 02973, 02974, 02975



ET0372 38.50

Chair suspension

Contents: 1 unit, with fixing material

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0041 46.01

Stop bar

Contents: 10 units

for model: 02972, 02973



ET0042 46.01

Utensils tray

Contents: 10 units

for model: 02972, 02973



ET0049 101.01

Chipboard table top (25 mm) W/D 75 x 65 cm

for Ergo-I: 02970

Materials/decors see appendix, incl. fixing material



ET0050 105.69

Chipboard table top (25 mm) W/D 130 x 65 cm

for Ergo-I: 02971

Materials/decors see appendix, incl. fixing material



ET0051 140.92

Chipboard table top (25 mm) W/D 75 x 65 cm

for Ergo-III: 02974

prepared for book storage if required

Materials/decors see appendix, incl. fixing material



ET0052 170.29

Chipboard table top (25 mm) W/D 130 x 65 cm

for Ergo-III: 02975

prepared for book storage if required

Materials/decors see appendix, incl. fixing material



ET0077 14.46

Cover

Contents: 10 units

for model: 02970, 02971, 02972, 02973, 02974, 02975



ET0069 14.46

Metal plugs

Contents: 5 units

for model: 02970, 02971, 02972, 02973, 02974, 02975

