



Material Notes

Cleaning and maintaining melamine resin-coated surfaces, such as chipboard panels, screen-printed chipboard panels, LIGNOdur, HPL boards, MDF or chip-plywood boards.

General information: Melamine resin-coated furniture surfaces do not require intensive cleaning since the non-porous surface ensures simple maintenance. Clean off minor soiling with a moderately damp cloth or sponge and remove more stubborn dirt with a little water and a gentle cleaning agent or suds. Quickly remove all excess water with a cloth or sponge. Then wipe wooden edges with dry rags.

Do not use any aggressive and/or abrasive cleaning materials. These can damage the surface.

Only use **cleaning cloths or rags or natural or synthetic sponges for cleaning**. Do not use any synthetic cleaning pads, microfibre cloths or steel wool.

Adhering limescale deposits/stains can be eliminated with a warm 10% vinegar or citric acid solution. Then wipe over again with clean, warm water.

If possible, remove any **marks** made by ball pens, felt pens, marker pens etc. before they dry in.

Arrange for a specialist to remove any **heavy-duty or difficult-to-remove stains** due, for example, to lacquers, adhesives, spray paints or dried-in marks left by ball-point pens, felt pens or board markers. You are advised to contact the VS Service department directly.